




3/4" Air Impact Wrench Item No : NC-6218 NC-6228

● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List

Twin Hammer Type

NC-6218 NC-6228



NO.	PART NO.	DESCRIPTION	QTY	NO.	PART NO.	DESCRIPTION	QTY
★	1	NC-6218T01 Backhead Assembly (01.06.14)	1 Set	●	24	NC-6218T24 Rotor Blade (6 PCS)	1 Set
★	2	NC-6218P02 Inside Trigger	1	★	25	NC-6218P25 Spring Pin (2 PCS)	1 Set
★	3	NC-6218P03 Outside Trigger	1	★	26	NC-6218P26 Cylinder	1
★	4	NC-6218T04 Pin (2 PCS)	1 Set	▲	27	NC-6218P27 Front End Plate	1
★	5	NC-6218T05 Screw (4 PCS)	1 Set	▲	28	NC-6218P28 Ball Bearing	1
★	6	---	1	★	29	NC-6218P29 Washer	1
★	7	NC-6218P07 Throttle Valve Plunger	1	★	30	NC-6218P30 Housing	1
★	8	NC-6218P08 Throttle Valve Seat	1	●	32	NC-6218P32 O-Ring	1
★	9	NC-6218P09 Throttle Valve	1	▲	33	NC-6218P33 Hammer Frame	1
★	10	NC-6218P10 Spring	1	▲	34	NC-6218T34 Hammer Pin (2 PCS)	1 Set
●	11	NC-6218P11 O-Ring	1	●	35A	NC-6218T35A Standard Anvil (35A.36.37)	1 Set
★	12	NC-6218P12 Air Inlet	1	●	35B	NC-6218T35B 6" Extend Anvil (35B.36.37)	1 Set
★	13	NC-6218T13 Spring Pin (2 PCS)	1 Set	●	36	---	1
★	14	---	1	●	37	---	1
★	15	NC-6218P15 O-Ring	1	▲	38	NC-6218T38 Hammer (2 PCS)	1 Set
★	16	NC-6218T16 Spring Pin (2 PCS)	1 Set	★	39	NC-6218P39 Bushing	1
★	17	NC-6218P17 Reverse Valve	1	★	40	---	1
★	18	NC-6218P18 Spring	1	★	41	NC-6218T41 Hammer Case Ass'y (40.41)	1 Set
★	19	NC-6218P19 Steel Ball	1	★	42	NC-6218P42 Side Spade Handle	1
●	20	NC-6218P20 Gasket	1	●	45	NC-6218P45 Rubber Cap (for inside Trigger)	1
▲	21	NC-6218P21 Ball Bearing	1	★	46	NC-6218P46 Hex Key Wrench	1
▲	22	NC-6218P22 Rear End Plate	1	★	47	NC-6218T47 Washer (6 PCS)	1 Set
▲	23	NC-6218P23 Rotor	1	★	48	NC-6218T48 Screw (2 PCS)	1 Set